

HVAC-C500 Diagnostic & Troubleshooting Guide

Product: Commercial HVAC System | Model: HVAC-C500 | Document Type: TROUBLESHOOTING

1. Error Code H102 - High Refrigerant Pressure Alarm

Description: Compressor circuit 1 pressure switch trips above 425 psi.

- Corrective Action: Clean outdoor condenser coils with coil cleaner hose; verify condenser fan motor rotation.

2. Error Code H304 - Low Airflow / Filter Clogged Warning

Description: Differential pressure switch across filter bank exceeds 250 Pa.

- Corrective Action: Inspect and replace MERV 13 intake air filter elements immediately.